

ROSWELL SOLAR PATH LIGHT

Description

The Roswell Solar Path Light is a solar energy-powered path light. The fixture is equipped with motion sensor settings. Automatic operation and wireless design make for easy installation and use. The wireless design makes this fixture perfect for areas without low voltage wiring such as: gardens, pathways, campsites, and large estates.



ROSWELL SOLAR PATH LIGHT

Use Areas with Full Sun that Need a Solar Powered Landscape Light
Areas with Full Sun that Need Motion Detection

Finish Stainless Steel Construction with Opaque Diffuser

Includes Mono-Crystalline Laminated Glass Solar Panel
Battery - 18650, 2600mAh, 3.7V
Two Mounting Options: Flush Mount or with Included Stake
Three Modes of Motion Detection:

Constant Dim Light	30 Lumens
Standby	200 Lumens for 25 seconds
Motion	300 Lumens for 25 seconds

Warranty 2 Year Warranty on Roswell Fixtures

Integrated Lamp 1.8W, 5V, 3000K, CRI 83, IP65, 2 year warranty

ROSWELL-SOLAR-PL

Operating Instructions To turn on or off, press and hold the power button for five seconds.
To change modes between three available settings, press the button for one second.
Motion sensor is active at 20 to 26 feet distance at 90-degree angle.

ROSWELL SOLAR PATH LIGHT



INSTALLING THE GROUND STAKE

1. Dig a hole in the ground approximately 4" wide by 7" deep. When working with hard soil, use a rubber mallet to drive the stake into the ground.
2. Place the fixture in the center of the hole.
3. Use a level to ensure the top of the stake is 2" above the ground and that it is level vertically.

INSTALLING ON DECK APPLICATIONS

1. Use three #10 x 2" round head stainless steel deck screws to mount the fixture base to wood or composite deck material (deck screws not included).
2. Position the motion sensor in the direction which traffic regularly approaches.